

# Holznotenpult 11701/06/07

## Wooden Stand 11701/06/07

### Aufstellanleitung

Zum Befestigen der FüÙe Standsäule **2** umkehren und Spannschrauben **8** (3 Stück) bis zum Anschlag in Standsäule eindrehen (Abb. A). FüÙe **1** (3 Stück) aufstecken (Abb. B). ExzenterfüÙen **7** (3 Stück) so einsetzen, dass der Pfeil zur Standsäule zeigt. Durch Verdrehen der ExzenterfüÙen - *hierzu beigefügten Innensechskantschlüssel verwenden* - Fußteile an Standsäule spannen (Abb. C).  
 Auszug **3** in Standsäule einschieben und mit Holzschraube in gewünschter Höhe festklemmen.  
 Gelenk **5** mit Kreuzschlitzschrauben **9** (2 Stück) an der Notenauflage **10** befestigen. Gummischeiben **4** (2 Stück) in Aussparungen am Auszug einlegen, Gelenk **5** darüber schieben und Notenauflage **10** mit Verschraubung **6** (2 Stück) in gewünschtem Neigungswinkel einstellen.

### Assembly Instructions

TO ASSEMBLE FEET TO STAND, PLEASE TURN BASE COLUMN **2** DOWN AND SCREW THREADED LOCKING BOLTS **8** (3 PCS.) VERY TIGHT TO LIMIT STOP (PICTURE A). ATTACH FEET **1** (3 PCS./PICTURE B). INSERT LOCKING SCREWS **7** (3 PCS.) WITH ARROW POINTS TOWARDS COLUMN. USE ATTACHED ALLEN KEY TO FASTEN FEET TO COLUMN (PICTURE C).  
 INSERT EXTENSION COLUMN **3** INTO BASE COLUMN AND FASTEN WITH THE LOCKING NUT AT THE DESIRED HEIGHT.  
 ASSEMBLE WOODEN CONNECTING JOINT **5** TO DESK **10** WITH COUNTERSINK SCREWS **9** (2 PCS.).  
 PLACE RUBBER WASHER **4** (2 PCS.) IN PROVIDED SPACE OF EXTENSION COLUMN **3** AND SLIDE CONNECTING JOINT OVER. FASTEN DESK **10** WITH THE LOCKING NUT **6** (2 PCS.) AT DESIRED ANGLE.

